

# BUTLER SINK

## INSTALLTION INSTRUCTIONS

The Zomodo Butler sinks can be installed in various ways. The sink must always be undermounted, however the alignment of the bowl wall relative to the countertop edges has three options.

The diagrams show the three different options:

- A. Overhang
- B. Aligned
- C. Reveal (rebate)

The sink can also be installed with either the outer-front wall aligned with the cabinet doors, or set forward of the cabinets doors.

- 1. Aligned: Shown in Diagram A and designated by mark "X1"
- 2. Forward: Shown in Diagram B & C and designated by mark "X2"

The front wall of the sink should not extend further than the front edge of the countertop, Refer diagram D X3

The sink must also be positioned to leave a minimum of 4" between the outer-rear edge of the sink and the wall. This will provide enough space for the installation of a backsplash and for the faucet lever to be fully actuated with ease. Refer Diagrams.

The base cabinet that supports the Zomodo Butler sink should be at such a height to enable the sink to slide under the countertop. The Butler sink has 1" horizontal under-side flanges running front-to-back which will rest on the base cabinet. Apply a liberal amount of silicon on the base cabinet in the areas that the flanges will rest. The distance between the underside of the countertop and the top of the base cabinet should be slightly larger than the sink height. Approximately 1/16" is recommended. When the sink is installed (and before the silicone sets) the sink should be centred and the desired bowl wall/countertop edge alignment achieved.

